



**To Prevent Breakage and Chipping, Avoid:**

- Improper loading in dish racks.
- Piling heavy items on lighter items.
- Stacking dinnerware too high.
- Nesting cups.
- Lack of protective matting on floor of dishwashing area.
- High water pressure in dishwashing machine.
- No rubber guards on disposal unit or dishwashing machine.
- Hand-washing operation.

**To Prevent Scratches and Metal Marking, Avoid:**

- Stacking hot, wet dinnerware.
- Not regularly cleaning stainless steel benches.
- Overworking dinnerware.

**To Prevent Unnecessary Damage or Loss when Stacking:**

- Consider the size and type of your storage space.
- Never stack items that were not designed for stacking.